

INSTRUCTIONS FOR RETURNING BW-LPD-DAQ4000 FOR CALIBRATION SERVICE

All items required for calibration will fit accordingly in the large plastic case it was shipped in. This case is reusable and holds a lifetime warranty.

If you are unsure which items to send back, all pieces needed for calibration will have calibration stickers on them.

COMPONENTS REQUIRED

BW-USB-4000 CONTROL INTERFACE

BW-004(XL,S) TEST FIXTURE

BW-012 SENSITIVITY TEST UNIT (STU)

BW-155XL STU ULTRASONIC TRANSDUCER and CABLE

PIND PC
PC CONTROLLER

3200M7 SHOCK ACCELEROMETER and CABLE (optional)

NOTE: the BW-100C Shaker and the BW-PA-4000 Power Amplifier are not needed for calibration and are not recommended to be shipped to reduce the risk of damage and shipping costs. A host shaker, amplifier and cable set will be used to calibrate your system.

TOOLS REQUIRED

- Phillips Screwdriver
- 3/32" and 5/32" Allen Wrenches

DISASSEMBLY

Remove all the cable inputs to back panel of BW-USB-4000 control console. Remove the front half of the bench top (if BW-4017 PIND Station Test Bench is used) by removing the four Phillips screws located underneath the bench top. Disconnect the three cables to the BW-004(XL,S) terminal block. Remove the two 3/32" Allen screws that hold the terminal block to the shaker degaussing magnet (BW-020). Use caution to assure the flex cable is not stressed. Remove the BW-004(XL,S) Test Fixture from the shaker by removing the four 5/32" Allen screws on the base plate. Fasten the BW-004(XL,S) Test Fixture to the provided 4" x 7" piece of cardboard to prevent damage to the flex cable during shipping and handling. Place in provided box. You may include any cables that need repair or you would like to have tested.

PACKAGING

FIRST LAYER - place the BW-USB-4000 in the bottom of the provided plastic case and surround with the foam insert. NEXT LAYER - put in the laptop (in original box if available), followed by the BW-004(XL,S), BW-012 with BW-155(XL), 3200M7 on the top layer. Items will fit into the foam cut outs.